

UNIVERGE SV8100

VM8000 In-Mail User Guide

TABLE OF CONTENTS

Chapter 1 VM8000 In-Mail User Guide

| | | |
|-----------|--|-----|
| Section 1 | Sending Calls to a Mailbox | 1-1 |
| | To Forward your Phone to VoiceMail | 1-1 |
| | To forward all incoming calls to your mailbox | 1-1 |
| | To forward incoming calls to your mailbox when your phone is busy | 1-1 |
| | To forward incoming calls to your mailbox when you do not answer | 1-1 |
| | To forward incoming calls to your mailbox when your phone is busy or you do not answer | 1-1 |
| | To Cancel Forwarding your Phone to VoiceMail | 1-1 |
| | To cancel forwarding all incoming calls to your mailbox | 1-1 |
| | To cancel forwarding incoming calls to your mailbox when your phone is busy | 1-2 |
| | To cancel forwarding incoming calls to your mailbox when you do not answer | 1-2 |
| | To cancel forwarding incoming calls to your mailbox when y our phone is busy or you do not answer | 1-2 |
| | An Additional Way to Call Your Mailbox (from Outside) | 1-2 |
| | To call your mailbox from outside | 1-2 |
| | Additional Ways to Record a Message | 1-2 |
| | Quick Message from outside | 1-2 |
| | After you call an extension | 1-2 |

THIS PAGE INTENTIONALLY LEFT BLANK

VM8000 In-Mail User Guide



SECTION 1 SENDING CALLS TO A MAILBOX

To Forward your Phone to VoiceMail

To forward all incoming calls to your mailbox

- Press the Speaker key
- Dial 741 or press the Call Forward Immediate Function Key (if one is programmed on the phone)
- Dial 1 to Set
- Dial the VM Pilot Number
- Hang up

To forward incoming calls to your mailbox when your phone is busy

- Press the Speaker key
- Dial 742 or press the Call Forward Busy Function Key (if one is programmed on the phone)
- Dial 1 to Set
- Dial the VM Pilot Number
- Hang up

To forward incoming calls to your mailbox when you do not answer

- Press the Speaker key
- Dial 743 or press the Call Forward No Answer Function Key (if one is programmed on the phone)
- Dial 1 to Set
- Dial the VM Pilot Number
- Hang up

To forward incoming calls to your mailbox when your phone is busy or you do not answer

- Press the Speaker key
- Dial 744 or press the Call Forward Busy/No Answer Function Key (if one is programmed on the phone)
- Dial 1 to Set
- Dial the VM Pilot Number
- Hang up

To Cancel Forwarding your Phone to VoiceMail

To cancel forwarding all incoming calls to your mailbox

- Press the Speaker key
- Dial 741 or press the Call Forward Immediate Function Key (if one is programmed on the phone)
- Dial 0 to Cancel
- Hang up

To cancel forwarding incoming calls to your mailbox when your phone is busy

- Press the Speaker key
- Dial 742 or press the Call Forward Busy Function Key (if one is programmed on the phone)
- Dial 0 to Cancel
- Hang up

To cancel forwarding incoming calls to your mailbox when you do not answer

- Press the Speaker key
- Dial 743 or press the Call Forward No Answer Function Key (if one is programmed on the phone)
- Dial 0 to Cancel
- Hang up

To cancel forwarding incoming calls to your mailbox when your phone is busy or you do not answer

- Press the Speaker key
- Dial 744 or press the Call Forward Busy/No Answer Function Key (if one is programmed on the phone)
- Dial 0 to Cancel
- Hang up

An Additional Way to Call Your Mailbox (from Outside)

To call your mailbox from outside

- Dial the Automated Attendant number
- Wait for greeting
- Dial # and your mailbox number
- (Optional) Enter your Security Code if you have set one in mailbox options


Additional Ways to Record a Message

Quick Message from outside

- Dial the Auto Attendant number
- Wait for greeting
- Dial *
- Dial extension
- Leave message
- Hang up

After you call an extension

- Press Message or VoiceMail Function Key (if one is programmed on your phone)
- Leave message
- Hang up



UNIVERGE SV8100

VM8000 IN-MAIL USER GUIDE

NEC Australia Pty Ltd

Issue No. 1.0
INT-2066 (VM)

To view the latest issue of this document go to NEC Knowledgebase at <http://www.kbase.cns.nec.com.au> and search for NEC-10573.